BRIGGS & STRATTON

Home Generator Systems

Illustrated Parts List

100 Amp
Automatic Transfer Switch

Model 071020 Manual No. 201705A Rev. B (02/26/2008)

Exploded View - Model 071020



Copyright © 2007 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.

Illustrated Parts List - Model 071020

Item	Part #	Description
1	NSP	ASSY, Enclosure
2	NSP	BACK PANEL
3	195667GS	TRNSFR SWTCH, 100A, w/ Handle
4	*	PPHMS, #10 - 32 x 1/2"
5	*	WASHER, Ext. Tooth, #10
6	193689GS	WIRE, Copper
7	*	PPHMS, #6- 32 x 3/8"
8	193664GS	INSULATION, Dead Front
9	197279GS	CONTROL, Board
10	201685GS	SPACER
11	196094GS	GROUND LUG
12	*	WASHER, Lock 1/4"
13	192882GS	BREAKER Circuit, 100A
14	*	NUT, 1/4” - 20
15	192696GS	TERMINAL, Neutral
16	B4857GS	FUSE
17	192151GS	FUSE HOLDER
18	197355GS	CLIP, Latching Wire
20	196355GS	DECAL, CT Warning
21	B5106GS	DECAL, Connection, Utility
23	196520GS	DECAL, 100A, ATS
25	205395GS	DECAL, Warning Shock
26	190984GS	DECAL, Fuse
27	B4986GS	DECAL, Ground
28	192597GS	DECAL, Sensing, Utility
29	193450GS	DECAL, Breaker, Circuit
30	197294GS	DECAL, Contacts Rating
31	192150GS	SPACER
32	197198GS	DECAL, Wire Circuits
33	192770GS	BRACKET, Circuit Breaker
34	*	PPHMS, 8-32x 3/8"
36	*	LOCKWASHER, #10
37	*	PPHMS, #10 - 32 x 1/4"
38	193159GS	DECAL, Reinstall Barrier

Items Not Illustrated

	195728GS	CURRENT TRANSFORMER

* - Items without part numbers are common fasteners and are available at local hardware stores.